



The chest belt secures the subject and prevents falling over to the front. The chest belt straps do not pinch or restrict the athlete.

The chestbelt has to be put on with the h/p/cosmos logo at the front on the left hand side - above your heart. The vertical belt (1), to attach the carabiner, has to be put on below the shoulder belts (2), facing the body, to unload the seem at the joint (3).



-  [Safety arch](#)
-  [Danger precautions](#)
-  [Printout](#) [*.pdf]



order numbers	
h/p/cosmos chest belt, size XL (without karabiner)	cos14903-XL
h/p/cosmos chest belt, size L (without karabiner)	cos14903-L
h/p/cosmos chest belt, size M (without karabiner)	cos14903-M
h/p/cosmos chest belt, size S (without karabiner)	cos14903-S
h/p/cosmos chest belt, size XXS for children (without karabiner)	cos14903-XXS
Karabiner for h/p/cosmos chest belt	cos11687